

# ClearSonic IsoPac J Instructions

*Parts Included: (2) A2466x4, (2) AX2412x4, (1)S1266, (2) ST2466, (8) S2233, (1) BAR, (1) FAN*

*Recommended tools: Rubber Mallet, Gloves, Rubbing Alcohol*

1. Open boxes and check for damage. Call us immediately if you have any damaged or missing items. Save all your boxes and packing for as long as possible or at least a few weeks.
2. Stand up the main shield system in zig-zag formation, base channel on bottom.
3. Peel masking off panels.
4. Install H-channels on top of main shields. Outside edge of H-channel should line up with outside edge of shield below.

5. Find an assistant if possible to help you install the AX Height Extenders. Lubricate bottom of AX panels with rubbing or other quick-drying alcohol solution to aid installation.



6. Note hinge configuration of large shield system. Be sure AX will be able to fold 180 degrees in same direction as the base system once installed. Make sure edges line up. Don't seat AX panels completely until all are in place. Tap top of AX panels with rubber mallet to seat completely into H-channel.



7. With one person on each side, unfold the system and wrap around kit. Use your fingers to lift the panels at bottom cable cut-outs to pull or push system into final position.



8. Adjust Lid support bar to width between end panels and rest support bar J-hooks at least 4-inches from edge of end shields.



9. Lay rectangular S1266 on top center of IsoPac with at least a one inch over-hang in front and resting on support bar in back. Place ST2466 trapezoids on either side of lid center section.



10. Place Velcro on all four corners of S2233 baffles about 1-inch from corners and peel off paper to expose adhesive. Place baffles in position on shields. Have your assistant apply opposing pressure from opposite side to secure Velcro.



11. Clip fan to back of booth or to lid section to aid in air exchange.
12. Use end acrylic panel as door to enter IsoPac.

**Please contact us at 1-800-888-6360  
should you have any questions.**

## ClearSonic IsoPac J



Please contact us at 1-800-888-6360  
should you have any questions.  
[www.clearsonic.com](http://www.clearsonic.com)

