



ADJUSTABLE SHELVES

Particle resistant epoxy coated wire shelves, adjustable height.

FORCED AIR COOLING WITH AUTO DEFROST

Better cabinet temperature uniformity and defrost

REMOTE ALARM FUNCTIONS

High/Low temperature, power failure, door ajar / door open alert, sensor error, low battery alarms

STANDARD FEATURES

Backup battery for alarms, self closing door, probe test hole, Interior LED lighting

The NAB-140 is the most versatile Pharmacold model yet. It is equipped with a reversible door which can be mounted on the left or right side. It has also been specifically designed to fit under a counter or in tight spaces.

Unlike other medical fridges its size the air intake and discharge vents are located in the front of the fridge. Giving it the ability to be placed directly against a wall, no need for added space at the back for air flow. The Pharmacold NAB-140 is an asset to any medical institution or laboratory.

TECHNICAL INFORMATION

Type	Pharmacy Refrigerator
Cabinet Type	Under Counter
Cooling Type	Forced air cooling
Defrost Mode	Auto
Refrigerant	CFC-Free

PERFORMANCE

Temperature Range Celsius	2 - 8
Accuracy Celsius	0.1
Uniformity Celsius	+ /- 2

CONTROL

Controller	Microprocessor Thermostat
Display	LED

ELECTRICAL DATA

Power Supply (V/Hz)	115/60
Power (W)	138
Electrical Current (A)	1.2

DIMENSIONS

Capacity (L/Cu.ft)	140/4.9
Net/Gross Weight (Approx)	105-118kg
Exterior Dimensions (W/D/H)	23.5 / 25.25 / 32 inches
Interior Dimensions (W/D/H)	19.75 / 19 / 22.75 inches

FUNCTIONS

High / Low Temperature	Y
Power Failure	Y
Sensor Error	Y
Low Battery	Y
Door Ajar	Y

ACCESSORIES

Caster	Optional
Foot	4
Probe Hole	Standard
Shelves/Basket Quantity	2.5/-
Door Lock	Standard
Remote Alarm Contact	Standard