

Bed Support Bracket Installation

Tools Required:

- 9/16" socket and ratchet
- 9/16" Combination Wrench
- 3/8" Drill bit and drill
- Center punch
- Silver Sharpie
- Philips head screw driver

Step 1: Locate the Bed Supports and determine the left bracket and right bracket. You should be able to read the logo on the brackets when viewed from the back of the truck.



Step 2: Starting on the drivers side. Place the bracket into position and check clearance with the tailgate closed, adjust if needed.

Step 3: With the bracket in position, mark the 4 holes with the sharpie. Now that the holes are marked, you can remove the bracket, center punch the holes and drill to 3/8".



Step 4: Remove the two Philips head screws holding the tail light in. To remove the tail light you need to carefully but firmly pull the light housing rearward.

Step 5: With the tail light removed you can reinstall the bracket with the supplied bolts. Having the tail light removed allows access to install the nuts on the back side. To access the nut for the bolt on the bed floor, you may need to temporarily remove the spare tire.



Step 6: With the bracket installed and all the hardware tight, you can now reinstall the tail light and two Philips head screws.

Step 7: Repeat steps 2-6 on passenger side.