

Ramp Measure & Installation Guideline

Customer Name:	
Email:	When providing dimensions or diagrams always remember to provide A x B x C as shown above.
Mobile Number:	
Notes:	Λ
	A Height B Length
	C Width

Measuring tips:

- 1. Check the substrate or ground surface for any bumps or humps that the ramp will lay on.
- 2. If possible, view from ground level the step height when taking measurement this will ensure a more accurate measurement.
- 3. If you have access to a straight edge or level simply place it 90 degrees on top of the step and measure underneath it, this will allow you to measure 2 steps at once and will give you an accurate measurement.

Things you will need when installing:

- 1. Flexi blade (Stanley Knife)
- 2. Tape Measure
- 3. High grade silicon
- 4. White marker or white pencil
- 5. Straight edge or combination square

Installation guide:

- If the ramp needs trimming you can do this by marking where it needs to be cut, then by slicing the ramp gradually. We
 recommend using a straight edge or combination square to help mark and run blade against.
- 2. If ramp requires xing in place simply put a silicon bead, make sure you run the silicon in a direction that will allow trapped water to escape from under ramp. This will avoid any mould in future.

SELECT	SIZE	WEIGHT	PRICE	QTY
	25mm x 1070mm x 205mm	3.8kg	\$93.60	#
	30mm x 1080mm x 310mm	7.3kg	\$156.00	#
	45mm x 1280mm x 460mm	17kg	\$238.00	#
	60mm x 760mm x 750mm	21kg	\$294.00	#
	60mm x 920mm x 350mm	11.3kg	\$174.00	#