

TABLE OF CONTENTS

PRODUCT INFORMATION

Safety Precautions	4
Parts	6
Product	7
Dimensions	8
Remote Control	9

PRODUCT INSTALLATION

Seat Installation10)
Remote Control Installation12	

PRODUCT OPERATION

How to Use	.14
Maintenance & Cleaning	.15

TROUBLESHOOTING

Tips & Specifications16	ŝ
Troubleshooting & Warranty1	7

SAFETY PRECAUTIONS





IMPORTANT SAFEGUARDS

• When using electrical products, especially when children are present, basic safety precautions should always be followed.

READ ALL INSTRUCTIONS BEFORE USING

- · Do not overtighten any connections.
- For use with 120V 60Hz: Power supply must be a 15 Amp GFCI outlet.
- The electrical cord must be connected to a GFCI outlet.
- The GFCI outlet should be 1 ft. above the floor.
- Install only in well-ventilated areas to avoid excess humidity.
- Do not install in narrow toilet stalls or in shower stalls.
- Install only where direct contact with water is minimized.
- Do not install near any heat source.
- Avoid using extension cords if possible. Consult with a certified electrician where extension cords are necessary.

DANGER - TO REDUCE THE RISK OF ELECTROCUTION

- Do not use while bathing.
- Do not place or store product where it can fall or be pulled into a tub or sink.
- Do not place or drop into water or other liquid,
- Do not reach for a product that has fallen into water. Unplug immediately.

WARNING - TO REDUCE THE RISK OF BURNS, ELECTROCUTION OR INJURY TO PERSONS:

- Close supervision is necessary when this product is used by, on, or near children.
- Use this product only for its intended use as described in this manual. Only use attachments recommended by the manufacturer.
- Never operate this product if it has a damaged cord or plug, if it is not working properly, has been dropped or damaged, or has been dipped into water. Return the product to a service center for examination and repair.
- Keep the cord away from heated surfaces.
- Never drop or insert any objects into any opening or hose.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Connect this product to a properly grounded outlet only. See grounding instructions.
- Unplug this product before filling. Fill (reservoir) with water only.

SAVE THESE INSTRUCTIONS

PARTS

PRODUCT









DIMENSIONS

REMOTE CONTROL



<15.9(406) ▲.7(120)~8.3(210) ▲.7(120)~8.3(210)

Elongated type



Round type







20.8(528) 11.4(290)

SEAT INSTALLATION



1. Remove the seat from the existing toilet body.



- Release the nuts, and then remove the seat and cover.
- Store the seat in a proper place for future use.
- Turn off the water.

2. Install the T-Valve.



- Remove the existing water hose and then install T-valve to the bottom of the toilet tank. Ensure the rubber washer is properly seated and attach the original water hose to the T-Valve.
- To avoid damage to product or property, do not overtighten the T-Valve or hoses.

3. Fix the catch plate onto the toilet.



• Point the arrow on the catch plate towards the toilet tank.

4. Push the main body toward the catch plate completely.



- Push it until you hear a "click".
- When the product is not installed well, it may cause leakage.
- Adjust as needed before tightening bolts. Do not over tighten the bolts.



5. Connect bidet hose.

7. Plug in!



• After installing the T-valve, connect the supplied bidet hose from the center of the T-valve to the bidet.



- Plug in and be sure that the nozzle extends and retracts when powered on.
- Do not plug the power cord in with wet hands. Risk of electric shock.

6. Turn on the water and check for leaks.



• If leak occurs, check to make sure all connections are properly sealed. Contact Bio Bidet support for assistance.

Using inline carbon filter

Use of external water filter is only recommended in areas with known hard water issues. If a filter is used, it must be replaced every 3 months. This product is designed and intended for use exclusively with Bio Bidet DIB water filters. The purchase or use of any other water filter is not the responsibility of BBC Innovation. As such, any use of non DIB water filters is prohibited and will void the warranty for those Bio Bidet products. Bio Bidet will not be responsible for any resulting damages or claims related to the misuse or distribution of non Bio Bidet DIB filters.

HOW TO USE



1. Sit On The Toilet Seat

• Be sure to sit on the seat sensor. If the sensor is not occupied, all functions will not open

2. Wash, Bidet, Turbo

- Selected function can be used as described.
- When pressing the selected function again, the nozzle will oscillate back and forth to wash a wider range.
- Press the button once again to stop oscillate function
- The specialized water spray in Turbo function helps relieve constipation.

3. Dry Temperature Control

- Dryer operates for 3 minutes.
- Dryer temperature is adjustable by pressing "+" or "-" buttons.
- Dryer effect will be improved if you wipe the moisture before operating the drying function.

4. Massage

• Press the Massage button after activating a cleansing function for a pulsating effect.

5. Child Function

• Select this function to fully extend the nozzle and activate a low pressure and low temperature wash.

6. Nozzle Position Control & Water Pressure Control

• Press the corresponding arrow buttons to adjust the nozzle position and water pressure after a wash has been activated.

7. Stop

• Hold for 3 seconds to turn off. All operations will stop.

8. Energy Saving Function

- Yellow Seat and water temperature will be maintained at 89°F until occupied.
- Green Seat and water heater are turned off until occupied.
- Off Energy saving deactivated.

9. Seat/Water Temperature Control

• Press the corresponding button to cycle through the preset temperature options for the water and seat. The seat temperature will automatically reduce when occupied for more than 15 minutes.

10. Nozzle Cleaning

• Activates 3 rinse cycles before extending the nozzle for manual cleaning. Press the stop button when finished.

11. Night Light

 Hold the "+" button for 3 seconds while the seat is not occupied to turn on/off.

12. Automatic Tank Draining

 The tank will automatically drain and refill if the seat is not used for 48 hours. Hold the Stop and Water Temp buttons for 3 seconds to turn on/ off.

13. Sitz Bath

• Press the nozzle cleaning button after selecting a cleansing function to activate a 5 minute low pressure wash.

HOW TO USE (CONT.)

MAINTENANCE & CLEANING



14. Seat Sensor Bypass

• Hold the massage button for 3 seconds to activate or deactivate the seat sensor. This will allow the seat to be used without being occupied.

15. Reset

• Hold the stop button on the side control panel for 5 seconds. The seat will turn of after 3 seconds. Keep holding for another 2 seconds to complete the factory reset.

16. User Preset

• Nozzle position, water pressure, and temperature settings can be preset and stored for 2 users.

Cleaning Instructions

• Avoid using harsh cleaners to preserve the plastic material of the bidet seat. Wipe the surface with a damp cloth or neutral cleaning solution. Do not splash water onto the power plug.

Screen Filter Cleaning



- 1. Close the water valve.
- 2. Disconnect the water supply hose. Take the screen filter out and clean it with a soft brush.
- 3. Return the filter after cleaning and reconnect the water supply hose.
- 4. Open the water valve.

Draining of Tank



- 1. Remove the power plug from the outlet.
- 2. Close the water valve.
- 3. Press the release button and gently pull to remove the unit from the catch plate.
- 4. Use a flat-head screwdriver to open the drain plug.
- 5. The tank should be drained when the bidet seat is not going to be used for an extended period of time.

•

TIPS & SPECIFICATIONS

TROUBLESHOOTING & WARRANTY





	ITEM	SLIM 3		
Rated voltage		AC 120V, 60Hz		
Max. Power consumption		870W		
Pow	ver cord length	1.2 m		
Recommended inlet water pressure		99~106.6 psi		
	Wash Volume	0.13~0.21 gal/min		
Wash	Heater Capacity	800W		
	Temperature Control	4 levels (off-low-middle-high)		
Heated Seat	Heater Capacity	55W		
	Temperature Control	Room temp 122ºF		
Dry	Heater Capacity	250W		
Feed water temp. tolerance range		37-95°F (recommended 54-95°F)		
Usage room temp. tolerance range		T STATUATE (recommended 5)		37~104°F (recommended 50-95°F)
Dimension	Elongated	15.9" (406) x 20.8" (528) x 7.0" (178)		
Dimension	Round	15.9" (406) x 19.5" (496) x 7.0" (178)		
Weight	Elongated	10.5 lb (15.2)		
Net Weight (Gross Weight)	Round	10.2 lb (14.9)		

PLEASE CHECK THE FOLLOWING POINTS BEFORE

REQUESTING REPAIR SERVICE.

PROBLEM	CHECK LIST
Completely out of order	 Check if the power plug is not connected Check if the power supply or outlet has failed
Water does not spray out	 Check if the water supply is turned on Check if water valve is open Check if nozzle is blocked by foreign material Check if connection hose is bent
Water pressure is low	 Check if screen filter is blocked and clean if needed. Check if the water pressure is set at too low level.
Water is not warm enough	 Check if its temperature is set at off or low level, or economy mode
Seat is not warm enough	 Check if its temperature is set at off or low level, or economy mode
Water tank is drained intermittently	 Check if the automatic water draining feature activates.
Water is leaking	 Turn off the water supply valve and contact Bio Bidet support.

1 YEAR WARRANTY

Bio Bidet warrants its products to be free from manufacturing defects under normal use and service for a period of 1 year from the date of purchase. This warranty is extended only to the original purchaser.

For full warranty details, visit www.biobidet.com

Contact Bio Bidet customer support with any questions you may have.

847.458.2334 support@biobidet.com www.biobidet.com

Thank You



Technical Support/Customer Service 7900 S Route 31 Crystal Lake, IL 60014 T: 847.458.2334 U.S. TOLL FREE: 877.339.5214

> support@biobidet.com www.biobidet.com