

## HANDHELD SHOWERHEAD INSTALLATION INSTRUCTIONS





- You do not have to disconnect the water supply when removing the handheld showerhead.
- To remove the existing handheld showerhead wrap a soft cloth around the hose nut where the hose connects to the original showerhead. This protects the finish of the connector.
- Remove the hose by turning the nut clockwise by hand or with pliers. Make sure you do not lose the washer that is sitting between the hose and holder. Please note: If your washer is worn you may choose to replace it for a good solid fit.
- Remove the original handheld showerhead from the arm by twisting clockwise by hand or with pliers. Discard the old showerhead holder.
- Wipe the shower arm threads with a rag to remove old Teflon tape.
- Wrap Teflon tape around the shower arm threads two or three times. (Tape included.)
- Twist the replacement hand held showerhead holder onto the shower arm. Tighten the holder by hand. Do not use pliers and do not over tighten.
- Insert the included washer into the hose connected to the showerhead. Twist the hose onto the threaded connector attached to the showerhead holder. The tapered end (longer end) screws onto the handheld showerhead. Tighten the hose to the holder by hand. Do not use pliers do not over tighten.
- Place the handheld showerhead in the holder!