

**MICROBIOLOGY DEPARTMENT 7218**

**THE PRESIDENT  
CRANE GROUP INTERNATIONAL  
Attention: Mr Johan Kriek  
364 Summit Avenue  
Hackensack, NJ 07601 USA**

Your ref: Flip top

Our ref: 17/37/7

Enquiries: 428-6172/3

Date: 2005-05-25

Page 1 of 2

2533433/05-1022/Y 57207a

**SUPPLEMENTARY REPORT****1. SAMPLE RECEIVED**

Alexapure Go® Portable Water Filtration Bottle – Patented flip top (24oz) bottles (design to protect the main spout and top of the bottle from any impurities) were received for microbiological evaluation. Tested on 2005-04-06, 2005-04-12, 2005-05-04 and 2005-05-11.

**2. TEST REQUESTED**

To determine the bactericidal efficacy of the Alexapure Go® water filtration bottle against five bacteria species.

**1. METHOD OF TEST**

- 3.1 A 10<sup>3</sup> bacterial suspension of each of the following organisms: *Escherichia coli*, *Pseudomonas aeruginos*, *Staphylococcus aureus*, *Salmonella typhy* and *Vibrio cholera* were prepared.
- 3.2 After thorough mixing the suspension were plated out as controls.
- 3.3 500ml of the suspension was placed in the flip top bottle and poured directly from the bottle into a sterile Erlenmeyer flask from which sampled were taken plated out for viable counts at 37°C after 48h incubation.
- 3.4 The samples were rested in accordance with:
  - 3.4.1 SABS SM 221 Edition 4 2001: Microbiological quality of water: General test methods.
  - 3.4.2 Selective growth media to culture each of the bacteria species.

## 4.RESULTS

Table 1: Microbiological examination.

**Alexapure Go® Portable Water Filtration Bottle**


Test organisms	Test organism load per 100ml	Percentage Reduction
<i>Pseudomonas aeruginosa</i>	$1 \times 10^5$	99,9%
<i>Escherichia coli</i>	$1 \times 10^5$	99,9%
<i>Staphylococcus aureus</i>	$1 \times 10^5$	99,9%
<i>Salmonella typhi</i>	$1 \times 10^5$	99,9%
<i>Vibrio cholera</i>	$1 \times 10^5$	99,9%

Note:

A log 3 reduction of each of the bacteria species was achieved.



RA ROOS  
MANAGER ; MICROBIOLOGY DEPARTMENT



R.MISTHRY  
MICROBIOLOGIST

## Confidentiality Notice:

This message is intended only for the use of the individual or entity to which it is addressed and in terms of Section 32 of the Standards Act, 1993, it contains information that is strictly confidential. If the reader of this message is not the recipient, or the employee or agent responsible for delivering this message to the intended recipient, you are hereby notified that any disclosure, distribution, copying or the taking of any action in reliance on the contents of this communication, is strictly prohibited. If you have received this communication in error, please notify us immediately by telephone to arrange for the return of the documents to us.

This report relates only to the specific sample(s) tested as identified herein. It does not imply SABS approval of the quality and/or performance of the item(s) in question and the test results do not apply to any similar item that has not been tested. (Refer also to the complete conditions printed on the back of official test reports.)