

SANITROL MB TO SANITIZE and DISINFECT NON-FOOD CONTACT SURFACES

To Sanitize hard nonporous surfaces:

Add **2 mL** of **SANITROL MB** per litre of water (150 ppm active) to sanitize hard, nonporous surfaces. Apply sanitizer use - solution with a cloth (preferably microfiber), mop, sponge, sprayer or by immersion, thoroughly wetting surfaces.

For sprayer applications, use a coarse spray device. Spray 6-8 inches from surface; rub with brush, if using on a non-porous surface such as concret. Do not breathe spray.

Treated surfaces must remain wet for 60 seconds.

Wipe dry with a sponge, mop or cloth or allow to air dry. Prepare fresh solution daily or more often if solution becomes visibly diluted, cloudy or soiled.

FOR DISINFECTING HARD NON-POROUS SURFACES

Add 6 mL of SANITROL MB per litre of water (450 ppm active quat)

Before use in federally inspected meat and poultry food processing plants and dairies, food products and packaging materials must be removed from the room or carefully protected.

When used on surfaces in areas such as locker rooms, dressing rooms, shower and bath areas and exercise facilities, this product is an effective fungicide against Trichophyton mentagrophytes (the athlete's foot fungus).

Apply use-solution with a cloth (preferably microfiber), mop, sponge, sprayer or by immersion, thoroughly wetting surfaces.

Treated surfaces must remain wet for 10 minutes. Wipe dry with a clean cloth, sponge or mop or allow to air dry.

Rinse food contact surfaces such as counter tops, tables, picnic tables, appliances and / or stove tops with potable water prior to reuse.

Do not use on glasses, dishes or utensils as a disinfectant.

For sprayer applications, use a coarse spray device. Spray 6-8 inches from surface; rub with brush, if using on a non-porous surface such as concrete. Do not breathe spray.

Note: For spray applications, cover or remove all food products.

NONACID TOILET BOWL AND URINAL DISINFECTANT DIRECTIONS:

Remove heavy soil prior to disinfection.

From concentrate: Add **22 mL SANITROL MB** to the toilet bowl or urinal and mix. Brush thoroughly over exposed surfaces and under the rim with a cloth, mop or sponge. **Allow to stand for 10 minutes and flush.**

From use solution: Empty toilet bowl or urinal and apply a use-solution of 6 mL per litre of water (450 ppm active quat) to exposed surfaces including under the rim with a cloth, mop, sponge or sprayer.

Brush or swab thoroughly, then **allow to stand for 10 minutes and flush.**

FOR USE ON FINISHED FLOORS: To limit gloss reduction use 6mL per litre of water. Apply with a damp mop or auto scrubber.

NAIL, MANICURE, SALON / BARBER INSTRUMENTS AND TOOLS DISINFECTION

BACTERICIDE / VIRUCIDE / FUNGICIDE DIRECTIONS:

Mix **6 mL** of **SANITROL MB** per litre of water (450 ppm active quat) to disinfect hard, nonporous instruments and tools. Completely immerse combs, brushes, plastic rollers, razors, scissors, blades, manicure, pedicure and other salon instruments and tools for **10 minutes**. For heavily soiled instruments and tools, a preliminary cleaning is required. Rinse thoroughly and dry before use.

Prepare a fresh solution daily or more often if the solution becomes visibly diluted, cloudy or soiled.

Note: Plastics may remain immersed until ready to use. Stainless steel shears and instruments must be removed after 10 minutes, rinsed, dried and kept in a clean, non-contaminated receptacle. Prolonged soaking may cause damage to metal instruments.

ULTRASONIC BATH DISINFECTANT DIRECTIONS:

Use **SANITROL MB** to disinfect hard nonporous non-critical instruments / objects compatible with Ultrasonic cleaning units. Pour fresh use-solution of 6 mL per litre of water (450 ppm active quat) directly into bath chamber. Preclean soiled objects. Place objects into unit and operate for a minimum of **10 minutes**, according to manufacturer's use directions. Remove objects and rinse with sterile water (sterile water for injection) or allow to air dry. Prepare a fresh solution for each use.

WHIRLPOOL, FOOT SPA DISINFECTION DIRECTIONS:

After using whirlpool, foot spa, drain and fill with a use solution of **6 mL** of **SANITROL MB** per litre of water (450 ppm active quat), to just cover the intake valve or 2 inches above the highest jet. Start the pump to circulate the solution. Wash down the deck, unit sides, seat of the chair lift and any related equipment with a clean swab, brush or sponge. Treated surfaces must remain wet for **10 minutes**.

After the unit has been thoroughly disinfected, drain the solution from the unit and rinse disinfected surfaces with fresh water. Wipe dry with a clean sponge or cloth or allow to air dry. Repeat for heavily soiled units.

LAUNDRY BACTERIOSTAT:

Use **120 mL** of **SANITROL MB** per 100 pounds of dry weight fabric. Dilute the appropriate amount of **SANITROL MB** in one to two gallons of water then add to the wash well in the final rinse. Re-treat fabric, after each washing.