



# NODAL NINJA 3 MKII

## QUICK REFERENCE GUIDE

For additional support:  
[www.nodalninja.com/userguides](http://www.nodalninja.com/userguides)  
[www.nodalninja.com/forum](http://www.nodalninja.com/forum)  
[www.youtube.com/nodalninja](http://www.youtube.com/nodalninja)



Attach upper unit to lower unit with knob.



Attach camera plate to camera.



Screw knob to rail plate to keep camera plate from slipping. It can also be used as a quick guide for easy assembly/disassembly.



Changing detent rings: Twist the rotator cap off of the lower unit. The bottom rotator will be loose, allowing for quick change of detent ring.

