

## Using the Pulsar® APX Oil

1. Screw in any 510 threaded cartridge using a clockwise motion until it locks into place (do not over-tighten).
2. Turn the unit on by pressing the button rapidly 5 times.
3. Press the fire button 3 times quickly to cycle through preset voltages. Desired voltage level is set when LED stops flashing.
4. To prime cartridge, press fire button 2 times to activate preheat mode. Display will pulsate under previously set voltage for 20 seconds.
5. After pulsing LED stops, the APX Oil is ready for use.
6. Hold power button and inhale to receive preferred amount of vapor.
7. Turn the unit off by pressing the button rapidly 5 times.

### Important Safety Warnings:

Do not expose to extreme temperature or direct sunlight. Do not drop the Pulsar® APX Oil or accessories. Do not drop or submerge in any liquid. Do not modify the electronics in any way. Only charge using Pulsar® brand chargers and Pulsar® brand accessories. Pulsar® APX Oil is intended for adults only. Do not sell or provide to minors. Keep all parts, concentrates, herbs, and liquids away from children and pets. Pulsar® APX Oil is not a medical device and is not intended to diagnose, treat, mitigate, cure, or prevent any ailment, disease, or other conditions. Consult a physician before use, especially if you suffer from heart disease or any other medical condition, or if you are pregnant or breastfeeding. Failure to follow any of these instructions could result in product damage, property damage, or personal injury.

### Limited Warranty:

Pulsar® APX Oil is guaranteed from manufacturer defects or malfunction from the original date of purchase for a period of 1 year. This limited warranty protects against manufacturer defects under normal use and does not apply to normal wear and tear, improper use, and accidental damage from dropping or submerging in liquid, improper cleaning, neglect, or any other damage that is not a result of defective materials or workmanship. If your Pulsar® APX Oil qualifies for servicing, we will repair or replace, at our discretion and expense, any defective parts or materials. Purchaser must provide a copy of the original dated sales receipt and may be required to provide shipping to return defective parts or materials. We intend to complete all repairs/replacements within 7 business days, although this timeframe may vary depending on shipping, replacement part availability, or other related factors. The lawful and proper use of this device is a condition of sale. Any improper use of the Pulsar® APX Oil will void the warranty. Warranty is non transferable. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state

For warranty servicing, contact us at:  
[www.PulsarVaporizers.com](http://www.PulsarVaporizers.com)

**PULSAR®**

ENJOY HIGHER CULTURE™

[www.PulsarVaporizers.com](http://www.PulsarVaporizers.com)

Manufactured By Pulsar®  
Asheville, NC 28806



USER MANUAL

Thank you for purchasing the Pulsar® APX Oil! In order to ensure safe use, please read all instructions and safety warnings before operating. Failure to follow instructions may result in injury and may void your warranty.

### BOOST MODE:

To boost the amount of vapor, activate the preheat mode (step 4) and continue your session (step 6) while preheat is active.

### TIPS:

- Do not over-tighten cartridge.
- Unit will get hot from “overuse”. Please let unit rest in between sessions.
- With more than 8-10 consecutive pulls, the unit will start to overheat.
- Unit has an auto shut-off feature and will power down after 4 minutes of inactivity.

### KIT CONTENTS:

APX Oil Vaporizer Battery  
Micro USB Charging Cable  
0.5ml Ceramic Cartridge

### TECH SPECS:

- Battery Size: 32.40mm x 22.10mm x 62.10mm
- Input: DC.5V, 1A
- Battery Capacity & Output: 1100mAh Lithium Battery
- Atomizer Resistance: 1.5Ω
- Pre-heating time: 20 seconds
- Voltage Settings: 2.8V / 3.2V / 3.6V
- Micro USB Charging Port
- 5-Minute Safety Auto Shut Off



### CHARGING INSTRUCTIONS

#### IMPORTANT:

You will need to fully charge your Pulsar® APX Oil before using it. Insert charging cable into unit & the other end into a dedicated USB port or wall socket if using AC wall adapter (Not Included). Set Pulsar® APX Oil on its side – do not let unit dangle from charge cord. This puts pressure on the charger plug that can result in the unit not charging fully. When it is time to recharge the unit after use, allow to cool, and remove the wax atomizer before laying the unit on its side to charge. This will help keep your concentrates in place.

- Battery Charge Time: Allow approximately 1.5 hours for the first full charge. Do not charge for more than 24 hours.
- Battery Charging: Battery indicator light will show charging connection is made by pulsing red.
- Low Battery Indication: When the battery requires charging, the battery icon will show red and will not heat.
- The Pulsar® APX Oil battery will deliver approximately 1.5 hours of continuous power, depending on use. Both the battery and chargers are designed to prevent overcharging. ONLY USE APPROVED PULSAR® CHARGERS! Failure to do so can damage the battery, which can result in property damage or personal injury and may void the warranty.