

# KEEP IT CLEAN



## EXCEL HAND DRYER WALL GUARDS

Wall Guards are designed specifically to fit securely underneath your Excel hand dryers, protecting your walls from water droplets that can be blown off wet hands by the powerful air stream of our high-speed hand dryers.

# EXCEL HAND DRYER WALL GUARDS



## WALL GUARDS




PART #89W

PART #89B

PART #89S\*



Microban's cutting edge antimicrobial coating product protection guards surfaces from the growth of bacteria, mold and mildew that can cause stains, odors and degradation of the surface.



Recommended location of adhesive strips

## Part ID Description

### ANTI-MICROBIAL WALL GUARDS

<b>89W</b>	<b>Microban® Wall Guard-White</b>	2 Wall Guards/Set*
<b>89B</b>	<b>Microban Wall Guard-Black</b>	2 Wall Guards/Set*
<b>89S</b>	<b>Wall Guard-Stainless</b>	2 Wall Guards/Set*

\*Set: 1 box of 2 wall guards

### SPECIFICATIONS

**Qty:** 2 per set

**Size:** 31 3/4" x 15 3/4" x 1/16"

**Weight:** 89S: 11 lbs., 89W and 89B: 4 lbs.

### INSTALLATION:

Mounted with 4 strips of construction grade 3M adhesive tape (included)

### MATERIALS

**89W/B:** Microban anti-microbial plastic: White or Black

**89S:** Brushed Stainless Steel

### INSTALLATION INSTRUCTIONS

1. Clean the wall surface with ISOPROPYL ALCOHOL prior to installation and make sure that the surface is dry and free of any dust and debris.
2. Center the Wall Guard underneath the hand dryer so that the top of the Wall Guard is 1" below the bottom of the dryer.

3. Carefully measure and mark the wall surface for placement of the Wall Guard with a pencil or temporary marker.

4. Four strips of double-sided adhesive are included for each panel. Apply the tape strips to textured side of black or white panel and smooth side of brushed stainless panel as follows:

- Lay out tape strips according to illustration at left.
- Remove one strip and apply to either right or left side to start.
- Press each tape strip firmly onto the plastic as it is applied.
- Continue until all 4 strips are applied.

**Note: Alignment is critical. Once placed on the wall, the Wall Guard cannot be re-positioned.**

5. Align the top edge of the Wall Guard with the markings on the wall and firmly press into place against the entire surface of the Wall Guard.
6. Optional: After guard is applied to the wall you may add silicone sealant around the edge.

### CLEANING INSTRUCTIONS

Clean the installed Wall Guard with mild soapy water and a soft cloth. Mild dish soap mixed with water in a spray bottle works best.

**DO NOT USE** any cleaner that contains any ammonia or abrasive cleansers to clean the surface.

\* Microban anti-microbial protection only available with the white and black wall guards.



# TIME TO THROW IN THE TOWEL®

ALLIED HAND DRYER, LLC  
San Antonio, TX

1.800.535.4393  
1.210.733.5918

www.handdryer.com  
sales@handdryer.com

JAN  
2017

16WGS0009