




light up furniture



User Instruction Manual



Using the Light Module

Operation of the light module for first time use, after module has been removed from the charger or battery has been run flat and re-charge.

Note: The on/off button is useful to set different colours and modes on multiple light modules that are in close proximity to each other



Press and hold the on/off button for 3 seconds or until the module turns on. Once the module is on it can be controlled without the use of a remote control. Press and hold the on/off for 1 second to change thru the colours and light modes until desired combination is found.

Once the module is on it can be controlled by the remote (2 x AAA Batteries Required)

Note: 1 x Remote can control multiple modules

Remote Function

		On/Off		
		*Brightness up or down for single led colour		
		*Speed fast or slow for RGB colour change modes		
				RGB colour change modes
				16 colour change options



Charging the Light Module

Note: It is recommended to charge the battery for a minimum of 12 continuous hours before first use of light module

The light modules built in 3.7V lithium battery is charged using our approved AC to DC charger.
 Charge times vary between 4-6 hours
 Working hours after full charge at full brightness vary between 8-12 hours

Charging indicator light
RED = Charging
GREEN = Fully Charged



Charging Port



Removing and Replacing Light Module


Note: *Dream Spheres, Numbers, Letters and some other small items do not support removable light modules.*

The Light Module can be removed for easy charging

Rotate the light module anti clockwise to unscrew from module housing

Remove light module from module housing

Rotate the light module clockwise to secure module back into housing





NOTE: *Be cautious not to cross thread light module into housing*



Light Module Types

Some Illuminated Wholesalers products carry 2 types of Light Module. Please refer to the items product description on the shop page for more information regarding your light module type

1w Output



2w Output



Specification

Input: AC 100 -240V - 50/60Hz
 Output: DC 5V 1A
 Switch types: IR/ RF remote
 Built-in battery: 3.7V rechargeable lithium battery
 Charging time: 3 - 6 hours
 Working hours after full charge: 8 - 12 hours
 Working temperature: 0- 70°C

Input: AC 100 -240V - 50/60Hz
 Output: DC 5V 2A
 Switch types: IR/ RF remote
 Built-in battery: 3.7V rechargeable lithium battery
 Charging time: 3 - 6 hours
 Working hours after full charge: 8 - 12 hours
 Working temperature: 0- 70°C

Cleaning and Care

With regular cleaning and care, your Illuminated Wholesalers products will provide years of superior performance and satisfaction. To maintain the finish quality of your Illuminated Wholesalers products, please follow the cleaning procedures provided below.

Normal Cleaning

Wash plastic surfaces with a soft cloth soaked in mild detergent and warm water.

Rinse thoroughly and dry with a soft cloth.

NOTE: Do not use solvents or abrasive kitchen cleaners.



Trouble Shooting

What can I do if the light module will not illuminate

- Check the light module is turned on at base (Ref, Using the Light Module)
- Check the battery is fully charged (Ref, charging the Light Module)
- If no result contact your dealer

What can I do if the remote will not work

- Check the light module is turned on at base (Ref, Using the Light Module)
- Check the remote has batteries (Ref, Using the Light Module remote section)
- Replace with fresh 2 x AAA batteries
- If no result contact your dealer

What can I do if the battery will not charge

- Check the charger is connected properly (Ref, Charging the Light Module)
- Check charger is showing correct light colour after 4-6 hour charge time
- Try another light module charger if possible
- If no result contact your dealer



Imported by:
National Hire Supplies
14 Cambridge Street
Rockhampton QLD 4700
www.nationalhiresupplies.com.au

