

AquaVas™

Stoneware Gravity Instruction Sheet

AquaCera
water filtration technology

INSTRUCTIONS

1. Remove the filter and elements from their protective packaging, checking each item against the diagram.

NOTE: This unit is for use with 2 filter elements only. There will be one element for each hole in the base of the top section.

2. Extreme cleanliness is important. Wash all parts, except the filter elements, before assembly.

3. Lid (1) is designed to cover the upper chamber (2) at all times when system is being used. The lid will also fit the lower chamber (3) if the unit is being used for storage of water only.

Filter Assembly

2. Place the sealing washer (5) over the threaded part of the element (4).

3. Insert the element (4) into the hole in the base of the upper chamber (2). Place another sealing washer (5) on the threaded end. There should be one washer (5) on either side of the element.

4. Secure the element in place by screwing the wing nut (6) onto the nipple part of the element. Repeat steps for second filter element.

Spigot Assembly

2. Place the washer (8) onto the threaded part of the spigot (7).

3. Insert the thread through the hole in the side of the lower chamber (3). Place the second washer (8) over the thread and secure the spigot in place with the nut (9).

4. Place the upper chamber (2) onto the lower chamber (3) and place the lid in position.

OPERATION

1. Ensure the spigot (7) is in the closed position.

2. Fill the upper chamber (2) with water.

NOTE: The first supply of filtered water must be discarded as it may contain loose material washed from the filter elements.

SERVICING

When the unit has been assembled as described above, weekly inspection and/or cleaning of the filter elements is the only servicing necessary.

To clean the elements:

1. Remove the elements from the upper chamber (2) by unscrewing the wing nut (6).

2. Hold the element(s) under running water or in a bowl of water and clean with a brush or ScotchBrite type pad. Always brush away from the nipple end.

NOTE: NEVER use soap or detergents to clean the filter element.

3. Reassemble as detailed in instructions above.

NOTE: The elements should be replaced annually.

NOTE: Regular cleaning of the housing is recommended, use mild soap and a non-abrasive material to clean the housing. This unit should not be placed in a dishwasher or microwave.

