



COMPHY

Developed for Spa. Designed for AHH.

**We recommend water-soluble massage oil, lotion or cream.**

We guarantee our sheets against staining for 300 washes, except when used with grapeseed and jojoba oils.

323.225.8234 | [WWW.COMPHY.COM](http://WWW.COMPHY.COM)

## WASH:

Pre-treat stains, following instructions for product concentration and treatment times.

Wash linen separate from any other material.

Use commercial grade laundry detergent.

**We recommend adding Tide Stain Release In-Wash Booster.**

Use liquid fabric softener sparingly to control static electricity build-up and improve wrinkle-free appearance.

Wash on Delicate cycle using hot water (up to 140°) and cool or cold water rinse.

Use slow spin cycle if available.

Use non-chlorine bleach, if desired.

## DRY:

Set dryer on permanent press cycle, medium heat with cool-down cycle.

Remove promptly and fold.

*See reverse for commercial laundering instructions.*

# SUGGESTED LAUNDERING INSTRUCTIONS SHANTUNG PRODUCTS | Programmable Machines

We recommend water-soluble massage oil, lotion or cream.  
We guarantee our sheets against staining for 300 washes, except when used with grapeseed and jojoba oils.

## **BREAK/SUDS CYCLE:**

10 minutes  
Hot water (140°)  
Low water level  
Alkali at 1500-2000 ppm

## **RINSE 1:**

2 minutes  
Hot water (140°)  
High level

## **RINSE 2:**

2 minutes  
Warm water (120°)  
High level

## **RINSE 3:**

2 minutes  
Cold water (80-85°)  
High level

## **FINAL RINSE:**

4 minutes  
Cold water (80-85°)  
Low level  
Sour to appropriate pH levels

## **EXTRACT:**

1 or 2 minutes  
Slow speed

## **DRYING:**

15 minutes at medium  
heat temperature (130-140°)  
5 minute cool down  
Remove from dryer immediately  
when done.

*All measurements are based on  
100 lbs of washer capacity.*

## **IRONING/FOLDING:**

If sheets are removed from the dryer and folded promptly, they should not need to be pressed. If you use an ironer, we recommend a temperature of 340° and suggested speed of 110 FPM. Adjustments may need to be made depending on type of machine used.

## **FOR OPTIMAL RESULTS:**

Only launder products in a full load.

Wash as soon as possible. Do not let soiled goods sit overnight. If that cannot be avoided, bag them in plastic bags to keep the air from oxidizing the spa oils; otherwise, they're more difficult to remove.

Do not use bleaches (they will oxidize oils, making them difficult to remove).

Wash in hot temperature of 140° with high levels of alkalinity.

Using solvents in addition to a high temperature alkaline bath is helpful.

*See reverse for consumer laundering instructions.*