

Mounting location for accurate measurements:

Choose a location that is not subject to direct weather elements. An ideal location is out of direct sun, on the North side of a building or in a shady spot.

Mounting instructions:

1. Mount the suction cup to the thermometer arm with the included screw.
2. Thoroughly clean the glass window.
3. After the area is completely clean, press the suction cup to the window as desired.

Optional Measurement Adjustments:

There is a small brass screw on back of the unit to modify or re-calibrate the thermometer if needed. Factory calibration is the recommended setting. This adjustment is optional and only recommended if changes must be made.