

# Heat Press Silicone Upper Platen Cover

## Installation Instructions

### Contents:

- 1 silicone rubber pad with Velcro® edges,
- 2 individual Velcro strips.

### No Tools Required

### For your safety, please read all instructions carefully.

- If press is in use, power off and allow to cool down completely before assembly.
- To avoid any potential tripping hazard, unplug the power cord from the heat press and from the outlet and set cord aside. (Never pull cord to disconnect, instead grasp from plug and pull to disconnect.)

1. Remove paper from adhesive side of Velcro strips.
2. Place strips adhesive side down on the top left and right edges of the upper platen.
3. Wrap cover around upper platen and join Velcro strips to secure.

**Note:** Cover should be removed for any heat applications that require a high temperature setting.

Not recommended for Transfers, Direct-to-Garment, or Sublimation.

