


* Visit: sdcsec.com/sargent For Installation video

801 Avenida Acaso, Camarillo, Ca. 93012 • (805) 494-0622 • www.sdcsecurity.com • E-mail: service@sdcsecurity.com

INSTALLATION INSTRUCTIONS LR100SGK ELECTRIC LATCH RETRACTION DEVICE KIT SARGENT MODELS: 8300, 8400, 8500, 8600, 8700, 8800 & 8900

Step 1

Remove access cover. Disconnect and discard all dogging components. Then remove the two pre-existing screws from the device.



Retrofit Installation Note: 42" or 48" exit devices that have been modified to fit a 36" or smaller opening, may not have the required space to fit the standard E. L. R. assembly. Always verify the distance from the end of the touchpad to the end rail, and if necessary, consult with the factory for appropriate selection.