## THE ORIGINAL RESINATOR XL Cleaning Instructions/Tips

- -We recommend cleaning all Resinator components between uses.
- -It's always easier to clean components right away. (Especially in water applications.)
- -All components can be sprayed down with water. (Except for motor.)
- -All collection tools are water safe.
- -Hang drum screen by metal clips to clothes line & spray with garden hose.
- Place drum screen in an enclosed container with isopropyl and shake vigorously.
- -Utilize isopropyl, followed by food grade H2o2, for deep cleaning.
- -Attach H20 connection/quick release coupler to garden hose and insert into drum shaft coupler attachment to flush center shaft with water.

