AlbaChem Venta-2M Cleaning Station

Installation Instructions

- 1) Open carton and carefully and remove contents:
 - A. Venta-2M Body
 - B. Stand
 - C. Stand support bar
 - D. Support Pole (2 pieces)
 - E. Gun Reel
 - F. Exhaust Hose
 - G. 4" PVC Elbow
 - H. Hardware (1 ¾" bolt X 4, ¾" bolt X 2, washer X 6, lock washer X 4, locking knob x 1)
- 2) Set up stand, attach stand support bar using ¾" bolts and large washers
- 3) Place Venta-2M body on the stand so the holes align. Secure 2M body to stand using the 4 bolts, washers, lock washers, and nuts.
- 4) Insert straight support pole into holder and secure with lock knob. Insert "L" shaped support pole into straight support pole.
- 5) Hang gun reel from to hooks and adjust gun reel to desired tension.
- 6) If desired attach PVC elbow to exhaust port.
- 7) Attach exhaust hose (not supplied).
- 8) Attach spot gun to gun reel and plug into supplied outlet on the Venta-2M.
- 9) Plug in Venta-2M.
- 10) Start vacuum via the on/off switch. Turn off vacuum when not in use.
- 11) DO NOT USE WITH FLAMMABLE LIQUIDS