## **GSXR 750 00-03 Hugger GSXR1000 00-02 Hugger**

## Part # 07015

## **Hugger Fitting Instructions - GSXR750 / 1000 '01on**

Fittings: a) 1x CFK07015 Strap Bracket for right hand swinging arm (2 piece)

b) 4x CBOLM60009 M6x20 Stainless steel allen bolts c) 1x CBOLM60007 M6x12 Stainless steel allen bolt

d) 4x CWASM60003 Black plastic washers e) 1x CWASM60002 M6 Shakeproof washer

f) 3x CNUTM60008 M6 Cage Nuts (Pre-fitted To Strap Bracket)

## General Information.

As with all huggers this model is designed to sit close to the tyre and should not be used with an oversized tyre. When fitting is complete the Hugger should sit centrally over the tyre when viewed from the rear. The tolerance in the right hand side mounting bracket allows adjustment to achieve this. As with all accessories the mountings should be checked for tightness.

\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*\*

The Job is easier with the bike on a paddock stand.

First remove the chainguard.

Unbolt the rear break-hose mounting clip on the top right side swinging arm.

This will allow the strap bracket to pass underneath the hose.

The strap bracket should be positioned against the front edge of the rear hose clip.

Mount the rear plate of the strap bracket by loosely attaching the single underside fastener using (c) and (e).

Offer up the Hugger and attach loosely to the chain side using 2x (f)

Attach to the right side bracket using 2x (b) and 2x (d). **NOTE. Both fingers of the bracket should be inside the Hugger.** 

Fully tighten all fasteners checking left/right alignment over the tyre as you do so.

Re-tighten the rear break hose mounting clip.

Check position of hugger over tyre. If adjustment is required loosen all fasteners slightly to allow realignment.



