

FILL PORT WATER SEAL

Tools Needed

No Tools Needed

This document will walk you through adding a fill port water seal to the Mopit MAX.

FOLLOW THESE STEPS

Step 1. Unlatch the 3 buckle latches

Step 2. Remove adhesive paper from the black seal

Step 3. Apply the black seal to the bottom of the upper tank as seen in the picture. The seal should be within 1/8 inch from the outer edge of the plastic.


Step 4. Re-attach the tank and attach the buckle latches

Purpose: This seal is to prevent water from flowing into the vacuum cavity when over-filling the solution tank. This seal will help preserve the life of the vacuum motor.




Buckle Latches (3)

Apply seal 1/8" away from this edge



Fill Port Water Seal



Fill Port Area