



NVA API0H HEADPHONE AMPLIFIER - ADDITIONAL INSTRUCTIONS

Connection to NVA passive pre-amplifier:

Option 1 (recommended for use with multiple sources) - use the 'TAPE REC' (sometimes called 'TAPE OUT') output to connect your API0H to your NVA passive pre-amplifier. This will bypass the pre-amplifier volume control, which is set to zero when listening to headphones only.

Option 2 – connect a single source directly to the API0H inputs.

Running in:

We have fitted heavy duty power supply capacitors inside your amplifier. These will need a couple of hours to 'form' when you first start using the amplifier – just play some music through them at normal levels. At first they may sound 'tight' or 'constricted'. After a couple of hours the sound will open up significantly and textures will fill in. For best sound leave the amps powered up when not in use (with volume at zero).