B-RAD

2-Slot Base Instructions



WOLF TOOTH | 3100 W PARK DR, BURNSVILLE, MN 55306 | www.wolftoothcomponents.com | 20180327 | B-RAD-2

PARTS INCLUDED:



BASE (2-SLOT)

2 slotted holes and 2 M5 threaded holes



M5X16 FASTENER (QTY. 2)

"Long" screws



M5X7.5 FASTENER (QTY. 2)


"Short" screws



Optional "shims" provide clearance between frame and slotted base

STEP 1. Select appropriate B-RAD accessories to fit your frame and desired B-RAD configuration.

STEP 2. Attach slotted base to frame using long screws extended through the base slotted holes.



B-RAD ACCESSORIES (sold spearately)



BOTTLE CAGES BOTTLE ADAPTERS BAGS STRAP ADAPTERS

TOOLS:

Hex wrenches T25 Torx key Side cutter

COMPATIBLITY:

Bottle cages and B-RAD accessories. Frames and forks with at least 2 standard 64mm spaced bottle cage braze-ons.

NOTES:

Torque short screws to 3-4 Nm and use light grease.

Use frame manufacturer torque specs to attach slotted base to frame using "long" screws.

STEP 3. Mount accessories or bottle cages to the 2-slot base using "short" screws.

