

How to Repair a Flow Style High-Cycle On/Off Valve (Insta 2) Using Kit #13687

These instructions will demonstrate how to replace components of a Flow Style High-Cycle On/Off Valve (Insta 2) with kit #13687.

Written By: Adam Dumas




INTRODUCTION


Hypertherm is in no way affiliated with the above mentioned manufacturer.

| J TOOLS: | DARTS: |
|-------------------------------------|---|
| • 1" wrench (1) | On/Off Valve Repair Kit #13687 (1) |
| 3/4" wrench (1) | O-ring #11145 (included in kit) (1) |
| • 7/8" wrench (1) | Poppet Seat #11141 (included in kit) (1) |
| | Bushing Stem #11273 (included in kit) (1) |
| | High-Pressure Valve Seal #11276 (included in kit) (1) |
| | Back-up Ring #11274 (included in kit) (1) |
| | Actuator #12129 (1) |
| | Valve Body #11272 (1) |
| | Nozzle Tube #11358-4 (1) |
| | Blue Goop #11111 (1) |
| | Isopropyl Alcohol (1) |

Step 1 — How to Repair a Flow Style High-Cycle On/Off Valve (Insta 2) Using Kit #13687



- Always make sure all high-pressure water has been removed from the valve by the following machine manufacturers' safety instructions. Failure to do so can cause severe injury or death.
- Turn OFF all water pressure to the on/off valve
- Turn the on/off valve ON to raise the poppet stem from the high-pressure seat.




- (i) The valve kit components can be replaced with the valve body in the mounting collar
- Unthread the <u>nozzle tube</u> from the valve body using a 3/4" and 7/8" wrench.

Step 3




- Turn the air to the actuator OFF at the controls
- Disconnect the air tube from the actuator.
- Unthread the actuator from the valve body using 1-1/8" wrench.




- Remove the old valve components from the valve body with the included dowel.
- Thoroughly clean the interior/exterior of the valve body with isopropyl alcohol or a similar cleaning agent before replacing the components.
- *i* Visually inspect the top and bottom of the bore for cracks/blemishes. If excessive wear or cracks are visible, replace the <u>valve body</u>.

Step 5




- Put the <u>bushing stem</u> onto the poppet stem.
- With the O-ring down, slide the <u>high-pressure valve seal</u> onto the poppet stem behind the bushing stem.
- Apply a high-pressure lubricant or similar (<u>11136</u>) to the outside diameter of the high-pressure valve seal.



- Put the <u>back-up ring</u> with the concave side towards the high-pressure seal on the poppet stem behind the high-pressure seal.
- Put the poppet stem, with the point down, at the top of the valve body.
- Use the dowel to push the poppet stem down until the back-up ring is flush with the top of the bore.

Step 7



- Apply <u>Blue Goop</u> to the top of the valve body threads.
- Thread (hand tighten) the actuator to the top of the valve body.
- Reconnect the air line to the top of the actuator.



- Apply Blue Goop to all surfaces of the high-pressure seat.
- Put the high-pressure seat at the bottom of the valve body.
- Put the <u>O-ring</u> behind the high-pressure seat so it is held in place.

Step 9



- Turn the air to the actuator ON to relieve the pressure from the poppet stem.
- Thoroughly clean the nozzle tube of all the Blue Goop.
- Reapply Blue Goop to the threads of the nozzle tube.



- Thread the nozzle tube into the bottom of the valve body.
- Tighten the nozzle tube to the valve body using 3/4" and 7/8" wrench.
- Turn the air to the actuator OFF to set the poppet stem into the high-pressure seat.

Step 11



- Apply water pressure to the valve assembly to verify there are no leaks.
- Quickly cycle the valve on and off a few times to purge the system of all contaminants before installing the cutting head.
- Reinstall the cutting head and continue the cutting process.