



JLAB

QUICK START GUIDE

EPIC2

Bluetooth

PREMIUM WIRELESS EARBUDS

ACCESSORIES



EPIC BLUETOOTH



6 GEL CUSHION TIPS



CABLE MANAGEMENT CLIPS

CASE



USB CHARGING CABLE



CHARGING



1 Locate the Micro USB door and plug in the cable and connect the USB to a computer or AC power source.



2 Red light indicates charging and will turn off once battery is fully charged. Full charge is approximately 4 hrs.



3 To ensure the water resistance of your Epic, the cover for the Micro USB port must be firmly closed.

BLUETOOTH PAIRING




1 When power is off, press and hold for 10+ seconds. Voice prompt "Ready to pair" followed by blue and red blinking lights indicate Epic is in pairing mode.

2 Look for Epic2 BT in your device settings and connect. If a password is required type in "0000". Voice prompt "You are connected" followed by slow blue blinking light indicates connection.



NOTE: The Epic will automatically pair with the last device connected to when turned on.

BUTTON FUNCTIONS



VOLUME UP:
Click once.

TRACK FORWARD:
Click and hold 2+ seconds.

POWER ON:
Click and hold 3 seconds.

POWER OFF:
Click and hold 5 seconds.

ANSWER/HANG UP CALLS:
Click once.

ACTIVATE SIRI (iOS) OR "OK GOOGLE" (ANDROID):
Click and hold 2 seconds.

BLUETOOTH PAIRING:
See Bluetooth Pairing page.


VOLUME DOWN:
Click once.

TRACK BACKWARD:
Click and hold 2+ seconds.


CABLE MANAGEMENT CLIPS

NOTE: Optional cable clips may affect your Bluetooth® connectivity. Removing cable clips can improve connectivity. For more info: support.jlabaudio.com/hc/en-us/articles/212909187


1 Create a desired length by looping the cable. For best connectivity: Make sure the microphone doesn't come in direct contact with skin (leave the cord loose around back of neck).




2 Secure a cable clip on one end of the loop by pushing in from the top and bottom.




3 Secure the second cable clip on the other end of the looped cable.



4 Cable clips should be secured to both ends of cable.



FITTING



1 Place the earbud housing to your ear while wrapping the memory wire behind the ear.



2 Rotate earbud in ear canal and adjust memory wire to your desired fit.