


1

**Set Print Mode:**  
Uninet iColor  
2-Step Temporary Tattoo



- Must be in **Overprint**
- Page size must match media being used. (A4)

iColor 500/600: Ultra Heavy 3  
iColor 550/540: Coated Glossy  
iColor 560: Thick to 105g  
iColor 650: Ultra Heavy 3  
iColor 800: Thick to 163g

- Make sure design is mirrored

2



**White Overprint:**  
200% for lighter skin  
400% for darker skin

- The brighter white, slick matte side is the print side.

**Warning:**  
Never run the adhesive sheet through your printer!

3



Once the image is printed, place the adhesive sheet on top of the print.

The White (adhesive coated) side should be face down.

4




Run the 2 sheets together through a laminator on Medium - High heat setting.

This will remove any air bubbles

**Do Not** use carrier sleeve.

5



**Temperature:** 265°F/130°C


Place the sheets in the center of the press with the B sheet on top. Fold a corner of the B sheet for an easy peel.

6



Cover the sheets with a sheet of parchment or kraft release paper and press at 265°F / 130°C for 40 seconds with Medium - High pressure

7



Hold the A sheet flat on press and peel B sheet away in a smooth, low, and slow motion.


8



Use a scissor or a rotary cutter to cut out the individual design you wish to apply.

## Applying to Skin

1



Peel the thin plastic translucent top printed layer away from the white paper liner and discard the liner.


Lay the film down flat on the application area, white toner side DOWN.

2



Thoroughly wet a towel with warm water and press it directly onto the applied image with firm, even pressure for about one minute.

3



The plastic layer will dissolve during the application process.

When finished, lift the towel and wipe away any excess adhesive.

4



You now have a temporary tattoo that will last for up to 2 weeks if proper care is taken. Apply moisture for additional durability.

### Tech Tips

- Smooth, clean, hairless skin is suggested when apply the tattoo, otherwise results will vary.
- Alcohol can be used in place of warm water when cleaning the application area if the skin is excessively moist.
- Regular application of moisturizer will prolong the life of the tattoo. Dry skin will cause the tattoo to flake prematurely.