

Setup guide

1 Unpack



A1600BT DECT 6.0
Amplified Cordless
Phone



ClearSounds 1-800-965-9043



Telephone handset



A1600BT base station



Telephone cord




AC power adapter assembly



Three rechargeable AAA NiMH
batteries




Carrying clip



User's Guide Please refer to this
guide for additional instructions.

2 Power


Plug in



To AC outlet

To phone jack

Charge









1.








2.











Prior to use, charge for 24 hours.



3 Call

	Place	Answer	End
	<ol style="list-style-type: none"> Dial . Press . 	 <ol style="list-style-type: none"> Lift Press . 	Press  .


	Place	Answer	End
	<ol style="list-style-type: none"> Press . Dial . 	Press  .	Press  .

4 Volume

	Adjust	Amplify	Maximum
	 <ol style="list-style-type: none"> Volume DOWN   Volume UP  	 <p>AMP</p>	 <ol style="list-style-type: none">   +5  <p>AMP</p>

	Adjust	Press to adjust ringer volume (or speakerphone volume during calls).
		







5 Messages










If you prefer to retrieve your messages by using voicemail through your telephone service provider, do not turn on the answering machine.

To retrieve your messages using the A1600BT answering machine, take these steps. (Use the base).

Turn on the answering machine

- Menu 
-  to TAM setup, Select 
- Select 
-  to ON, Select 

Record your outgoing message

- Menu 
-  to TAM setup, Select 
-  to Outgoing Msg, Select 
-  to Record OGM, Select 
- After the tone, speak to record, End 