



CTA LABEL 1

Aftercare/Cleaning Instructions

Regular Care

- Protect from direct sunlight.
- Vacuum regularly using low suction.
- Rotate reversible cushions regularly.

Spot Cleaning

- Treat spills and stains as soon as possible.
- Gently scrape any soil or mop liquid from the surface of the fabric.
- Do not scrub.
- Apply proprietary cleaning agents strictly according to instructions to remove the residue of the spill.
- Do not saturate the fabric or interior with water or other cleaning liquids.
- May be spot cleaned with dry cleaning solvent.

Cleaning

- Do not remove cushion covers for separate cleaning, even though they do have zippers.
- Clean with hot water extraction machine (hot).
- Professional cleaning recommended.
- Do not use dishwashing or laundry detergent.
- Use only upholstery detergents.
- Do not wet filling.
- Dry in shade away from direct heat and sunlight.
- Allow to dry thoroughly before re-use.

OR

- Clean using on-site dry cleaning machine (P).
- Professional cleaning only.
- Do not wet filling with solvent.
- Extract solvent thoroughly after application.
- Wipe gently, do not rub.
- CAUTION – exhaust solvent vapour outside building.
- Provide adequate ventilation during cleaning and drying.
- Allow to dry thoroughly before re-use.
- Avoid use of room during drying period.

OR

- May be shampoo cleaned using upholstery shampoo.
- Do not use dishwashing or laundry detergents.
- Do not wet filling.
- Wipe gently, do not rub.
- Dry in shade away from direct heat and sunlight.
- Allow to dry thoroughly before re-use.



COMMERCIAL TEXTILE ASSOCIATION
OF AUSTRALIA & NEW ZEALAND
LIMITED