

<u>Cafetto® MFC Green Milk Line Cleaner</u> How to Use Guide

Directions:

- Ensure the white cap is tightly sealed and slightly loosen the green cap. Gently squeeze
 the bottle until reservoir measures 50ml, remove the green cap and pour from
 reservoir.
- 2. Add 50ml of MFC Green to 1 litre of warm water in a cleaning container. Ensure you replace the green cap and seal tightly after pouring the required dose.
- 3. Insert milk frother suction tube into solution.
- 4. Run entire solution through frother.
- 5. Repeat above procedure with 1 litre of clean water to rinse all the components thoroughly.
- 6. Do not mix with other chemicals.

