



- 1** Place the filter wrench on to the top of the filter housing to engage and with firm pressure turn the wrench counter-clockwise until it can be pulled
 - 2** To install a new PSF-10 filter cartridge, place the filter in the housing and using the wrench, turn the new filter clockwise until it stops.
 - 3** Prior to use, run the water fountain for at least 5 minutes to properly flush the system.
- Rated Capacity: 300 gallons (1,135 liters)
 - See installation guide for general installation conditions.



The PS-01 filtration system is certified by IAPMO R&T against NSF/ANSI 53 for the reduction of lead as well as NSF/ANSI Standard 372 for lead-free plumbing requirements.

Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system.