

WARRANTY



We are committed to producing the best concentrate vaporizers.

- You have 6 months warranty on your StoneSmiths' Piccolo battery.
- Chambers are not covered.

For additional information on your warranty, go to: <https://stonesmiths.ca/pages/trouble-shoot>



Scan to visit warranty page

BEWARE




- Chamber may be hot after use.
- StoneSmiths' products are not intended to diagnose, treat, cure, or prevent any disease or medical conditions. *If you are pregnant, nursing, taking medication for a condition, please consult your physician.*
- StoneSmiths' products are intended for and must be used only by persons of legal age.
- StoneSmiths' reserves the right to verify the age of any customer prior to purchase.



KIT INCLUDES



- 1x Piccolo concentrate vape pen
- 1x Double-headed pokey tool
- 1x USB charging cable
- 1x User manual



LEARN



& CONNECT

Discover exclusive features, test prototypes, interact with StoneSmiths' development team, contribute ideas, submit enhancement request, and more.



STONESMITHS'



Join the StoneSmiths' community



Discover more StoneSmiths' products


PICCOLO

CONCENTRATE VAPE PEN
VAPORISATEUR DE CONCENTRÉ


SETUP



- Press 5 times to turn on/off.
- Pull to detach the magnetic mouthpiece.



- Load concentrate on the **top center** of the heating ceramic platform. Make sure the concentrate is not hanging on the chamber's wall.



SETUP



PRIME

Priming is needed for new chambers

- Load concentrate.
- Press and hold the power button for 3 seconds then release.
- Repeat 3-4 times until the concentrate is melted.

Press and hold the button to vape and enjoy.



Scan to watch How to Prime video

HOW TO



CHANGE TEMPERATURE

Press 3 times to switch temperature level.



Red: high temperature (720F/382C)



Green: medium temperature (640F/337C)



Blue: low temperature (572F/300C)

HOW TO



CHARGE

- Battery indicator.

●●● 100%

●●● 60%

●●● 30%

●●● Please charge

- Piccolo's battery fully charges in 30 minutes to an hour.
- Use Piccolo's cable included in the kit to charge it.
- Use power adapters between 0.5A to 2A.

HOW TO



CLEAN

- Pull out the splash guard to clean the mouthpiece.
- Do not soak mouthpiece or chamber in ISO*.
- Do not use any ISO inside the chamber.



Scan to watch How to Clean video

*Isopropyl Alcohol