



# DTF MINI PURIFIER

## User Guide



- Please read carefully before use

## ► Safety Instructions & Warranty

### Read the instructions carefully before use

1. Make sure the power cord is well-connected and reliably grounded when used.
2. Make sure the connected power supply is safely grounded.
3. Unplug the power if a long time you do not use.
4. Avoid using this product in extreme temperature environments, and avoid exposing this product to strong sunlight or high environments.
5. Check the product regularly. If the power cord is aging, please stop using it immediately.

## ► What's in the box

DTF Mini Purifier x 1

Power Cord x 1

Aluminum Foil Ducting x 1 & Clamp x 2

Manual x 1

## ► Getting to know the DTF Mini Purifier



## ► Specification

Power: 12W

Voltage: AC 110V

Noise: 52dBA

Exhaust air volume: 36cfm

Size of air duct connection: 45-55 mm / 1.77"-2.17"

Item size: 205 × 205 × 185 mm / 8.1" × 8.1" × 7.3"

## ► How-tos

**Step 1:** Use aluminum foil ducting to connect the air inlet.

- (1) Remove the smoke extract vent of the DTF oven with a screwdriver.
- (2) Place the conversion interface in the oven smoke extract area and fix it with screws.
- (3) Use aluminum foil ducting to connect the conversion interface and the air inlet of the purifier, then fix clamps.

**Step 2:** Plug in the power cord.

**Step 3:** Press the switch to turn on.

Note: Rotate the Speed control knob to adjust the speed.

**Step 4:** After use, press the switch to turn off& unplug the power cord.

## ► Cleaning and Maintenance

- Make sure to unplug the power cord before cleaning or maintaining this product.
- Do not rinse this product directly with water or other liquids.
- Please keep the outside of the product dry.

## ▶ Q&A

**Q:** How should I connect the air vents of the DTF oven and the DTF purifier?

**A:** Step 1: Remove the smoke extract vent of the DTF oven with a screwdriver.

Step 2: Place the conversion interface in the oven smoke extract area and fix it with screws.

Step 3: Use aluminum foil ducting to connect the conversion interface and the air inlet of the purifier, then fix the clamps.

Note:

- The conversion interface is included in the accessories of the DTF oven.
- It is recommended to use screwdrivers to operate it, which is safer and faster.

**Thank you so much for the purchase!**

Register and get extended warranty

[www.offnova.com](http://www.offnova.com)