


## Getting to know MUGUM



## How-tos

1. Cut off the pattern from transfer sheet / Draw on laser copy paper  
Note: The image you draw on the paper should be mirrored.



2. Wrap around mug blank (fix with Heat Resistant Tape)



3. Insert the mug when LCD is Flashing  
Note: Use in a well-ventilated area, the vapors from heating process may be irritating to sensitive individuals.



4. Secure the mug & wait for the beep  
Note: Do not unlock the lever before the countdown is completed, otherwise the LCD will show up "ERR". At this time, please secure the mug again and wait for completion.



5. Unlock lever and remove mug by handle carefully. Place mug on a heat-resistant surface until it cools down completely. (Mug will be very hot after transfer, please avoid contact!)



Note:

1. When reach the set temperature, machine will turn off automatically after 3 minutes of inactivity.
2. Machine's high operating temperatures can cause burns, damage surfaces, and start fires. Always avoid using machine on heat-sensitive surfaces.
3. After power off, wait for the machine to cool down completely.

## Any questions or concerns?

Please simply drop a message to the OFFNOVA support team <[support@offnova.com](mailto:support@offnova.com)>. Most issues can be resolved quickly.

## Safety Instructions

Please read the entire document prior to operating OFFNOVA MUGUM.

- ⚠️ **WARNING** indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.
- ⚠️ **CAUTION** indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.
- 🔥 **HOT SURFACE:** Heat plate and stand are hot while in use.
- ⚠️ **CAUTION:** Use in a well-ventilated area--vapors from heating process may be irritating to sensitive individuals. In case of skin irritation, immediately wash skin with soap and water; for contact with eyes, immediately flush with water. If irritation persists, seek medical attention.

To reduce the risk of explosion, fire, death, electric shock, scalding, or injury to persons when using this appliance, follow basic precautions, including the following:

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by person responsible for their safety.

## Warranty

All OFFNOVA products come with one-year manufacturer warranty and 30-day return service. The warranty period is 1 year from the date of the purchase unless otherwise stated.

Register and get an extended warranty:  
[www.offnova.com](http://www.offnova.com)

For any questions or suggestions, please email the OFFNOVA team at: [support@offnova.com](mailto:support@offnova.com) or visit the support page of [www.offnova.com](http://www.offnova.com)

Thank you for your selection!

