

# User guide

## Ultrasound scare against martens, rats and mice

Thank you for purchasing our products.  
Read this user guide carefully before use.  
If you have any questions about your order or about this product, please feel free to contact us.

### PRODUCT DESCRIPTION:

The ultrasound scarer is used to fight rodents, including martens, rats and mice. It works using ultrasound and pressure waves. The ultrasound scarer does not bother humans, dogs and cats, nor does it affect electronic installations. It operates in the frequency range 16- 50 / 25kHz. It switches automatically and regularly between different frequencies.



### SPECIFICATIONS:

Product name	Triple-rodent-repeller
Model no.	VS-361N
CE marked	Yes
Supply	100-240VAC - 50 / 60Hz - 0.2A
Output	9 VDC - 500mA
Waterproof	Place dry
Coverage area	Up to 550 m2 in 360 degree circumference

### INSTALLATION:

#### 1st:

Remove the ultrasonic scanner and the power supply from the box. Make sure they are intact and undamaged. Should there be any damage - contact us immediately and do not use the parts.

#### 2nd:

The power supply is plugged into the ultrasonic scraper in the connectors shown. The power supply in the socket and the power is turned on. The ultrasonic scarer now provides audible sound or one or both of the small lights on top of the unit are turned on.

#### 3rd:

Test the ultrasound scarer by putting it in test mode.



You will now be able to hear a sound.

Next, set it to the desired effect on the button at the bottom. You can choose from the following programs:

1. Plug into the power supply
2. Program selection
  - TEST - Simulates sound
  - ULTRA - Ultrasound that effectively scares mice
  - TRANS - Air waves that effectively scare moths and rats
  - DUO - combination of both (recommended)

#### 4th:

Place the scarecrow in the desired place. You should observe:

- Place on a dry surface and 20-50 cm above level
- Do not place the ultrasonic scarer on the carpet
- Clear around the scarecrow so that there are no immediate obstacles like it in working.

### NOTE

**Typically it will take a few days before increased activity of the rodents is heard and after some time (max. 4-6 weeks) they will have moved and the activity will stop.**

### WARNINGS:

- ✦ Do not use if it is damaged during transport. Contact us immediately if this is the case.
- ✦ For indoor use only
- ✦ Keep it away from children due to the use of electricity

### NEGOTIATED BY:



**www.agrini.dk**  
Skånsomme produkter

Navervej 6, 7430 Ikast  
[info@agrini.dk](mailto:info@agrini.dk)  
Tel. +45 4117 7868