

Mobile Power Center (MPC) Quick Start Guide

CHARGING: We have shipped your new Mobile Power Center (MPC) with a state of charge at roughly 60%. As a result, you will need to fully charge the MPC to utilize its full capacity.

Charging Instructions:

- Plug the included "Charge Connector" into your AC adapter to create a male connector tip.
- Plug the AC adapter's newly created male tip into the red colored port labeled "Input" on the side of the MPC.
- Plug the AC adapter into any standard wall outlet to begin charging. When all 4 blue indicator lights on the side of the MPC remain solidly illuminated, charging will be complete. Always disconnect the AC adapter after the MPC is fully charged.

WARNING: Never charge more than 1 MPC from a single AC adapter (i.e. do not "dual charge" using a Y-Cable). Doing so will damage the AC adapter.

CAPACITY CHECK: To check the current state of charge of the MPC, quickly press and release the power button and view the 4 blue indicator lights on the side of the MPC. Capacity remaining corresponds to the number of lights that illuminate:

1 Light = 0 - 25% 3 Lights = 50 - 75 % 2 Lights = 25 - 50% 4 Lights = 75 - 100%



Mobile Power Center (MPC) Quick Start Guide Continued

LIGHTING: When powering LED lights using the MPC, please proceed as follows:

- Make sure "on/off" switch located on light fixture power cord is set to the "on" position.
- Plug light fixture power cord into the green colored port labeled "output" on the MPC.
- Press and hold power button on the MPC for roughly 5 seconds to engage power.

Please Note: LED lights can run at any voltage setting on the MPC. However, for the longest runtimes, please slide the "voltage selector to 12V.

For detailed illustrated instructions on charging & lighting operation, and important storage & handling information, please visit the MPC product page on our website at:

dslgroup.com/mobile power center p/ledbatmpc.htm

Thank you for your business! DS&L Team (800) 468-1488

> P (630) 285-9660 F (630) 285-9670