VMI 2550 Buffer



Read this sheet to set the machine up

Unpacking the machine

The machine has been carefully packaged to protect it during transit, you will need to repackage it in the same box if you ever send it to us so take a note of how it comes out of the box.





Please keep packaging in case the machine needs to be returned at any point.

Locating the machine

Place the machine on a sturdy, flat surface near a power socket.




Removing the protective foams


There are two pieces of foam inside the machine that you must remove before powering up. They protect the motor and buffing wheel during transit.

Simply unscrew the side screws, lift off the lid and remove the two pieces of foam, as shown below.









Store them somewhere safely, along with the rest of the machine's packaging.

Once you have removed the foams, you should re-attach the lid and tighten the screws.

Install the repair time credit

The machine will come with a brand new buffing wheel already installed, this is good for 500 minutes of repair time that the chip contains.



To install the chip and load the repair time, simply plug the chip into the socket on the back of the machine prior to powering up, when you power up the credit will appear on the machine's display.

The buffing solution



With each consumables pack you get two bottles of buffing solution.

Keep them close to the machine as buffing solution is required for every repair you run.

Contents

The contents of the box is listed on the back of this sheet. Please check to make sure that the contents are complete.

If you have any queries with the content of the box, please contact Technical Support, Monday to Friday, 9am to 5pm on:

0800 412 5424

VMI 2550 Buffer



Box Contents



VMI 2550 Buffer Machine



Bottle of buffing solution



Repair credit chip



Power lead



Buffing wheel (Installed in the machine)



Turntable mat (Installed on Turntable)



Cleaner disc



User guide