

### Included Components

1) Select a location for your Yates Protect Q9 facial recognition and thermal scanner

A good location will be near an entrance and an electrical outlet, with enough space for a socially-distanced line to form

2) Attach Base to Pedestal

Use appropriate Allen wrench and install the two ½ screws from the bottom of the base into the pedestal through the holes in the base (see A on right for location)


3) Install Display

Thread Display cords through square Pedestal cover (B) and washer (C) as pictured. Connect ethernet and power cables coming out of the bottom of Display (D) with ethernet and power cables in Pedestal (E)

Use included Allen wrench to secure Display to Pedestal with four ¼ inch screws

4) Plug included electrical cord at the bottom of the Pedestal (D) into an outlet and wait one minute

Your Yates Protect Q9 is ready to start scanning



### All Other Included Equipment

Allen wrench (2)

½ inch screws (2)

¼ inch screws (4)

Electrical Cord

