

How to use the Rotovac ShearDry / Shear Dry Upholstery Tool R-VAC-SHEAR Upholstery Tool

1. Attach you solution hose to the quick connect of the ShearDry at the end of the hide-a-hose.
2. Turn on the pump of your extraction cleaning machine. 75-150 psi is recommended.
3. With the cleaning head of the ShearDry pointed into the solution tank of the extractor or into a sink, squeeze the solution trigger and adjust the water flow-rate with the brass circular knob near the quick connect. Some of the water is vacuumed back into the two vacuum slots and some of the water will spray out.
4. Cover the flow control knob and the quick connect at the end of the hide-a-hose with the drawstring bag to protect the floor and to act as a heat shield.
5. With the cleaning head on the fabric, squeeze the solution valve trigger. You can clean up, back, left or right. As long as the cleaning head is on the fabric, there is no overspray or dripping. The ShearDry can clean in all directions.
6. If you keep the solution trigger on without the cleaning head in contact with the fabric, some of the water will squirt out. So, let go of the solution valve trigger BEFORE removing the cleaning head from the fabric.
7. When cleaning a type of fabric that repels water and / or the flow-rate is set too high, water drips out the side of the heading making the user think something is wrong. All you need to do is turn down the flow control valve to put out less water.