

Cleantank Instructions

USAGE PROCEDURE

1. Fill the tank $\frac{3}{4}$ full. Pour in entire bag of X-Soak. Fill the tank to the fill line with water.
2. Turn Cleantank on.
3. Add soiled wares to tank, ensuring wares are completely submerged.
4. After soaking, remove wares from Cleantank using the lift basket. Heat resistant gloves recommended.
5. Wash, rinse, sanitize food contact surfaces.
6. Rinse non-food contact surfaces.

DRAINING PROCEDURE

1. Turn Cleantank off. Remove any remaining items from the tank.
2. Replace lid and roll tank to floor drain.
3. Screw drain fitting into drain valve. Attach hose to drain fitting and ensure clamp is secure.
4. Remove drain cover and place end of hose in drain.
5. Remove tank lid and open drain valve.

This tank is warranted by Clean X-press LLC
Use only X-Soak soak tank powder, use of any other chemical voids warranty.
For service or questions about detergent for this tank please call:



30725 US HWY 19N #237
Palm Harbor FL 34684
877-870-5088

COMPATIBILITY SPECIFICATIONS

Equipment Type	Soak Tank Compatible	Soaking Time
Aluminum sheet pans, hood vents, pots, or other aluminum equipment	YES	Overnight (8-12 hours) for light soils, 3 to 4 days for heavy soils.
Stainless pans, oven racks, broiler racks, smoker racks, utensils, spoons, ladles, can openers, dish machine inners, and other stainless items	YES	30 minutes to 4 hours depending on buildup
Cast iron grates, pans, pots and other cast iron items	YES	2 to 12 hours depending on buildup
Ceramic mugs, plates, dishes and other similar items	CAUTION! Be careful not to break items when placing them in and removing them from the tank!	1 to 4 hours depending on buildup
Plastic cutting boards	CAUTION! Clean thick plastic items when the water is clean. May damage items if they are left in the soak tank for too long. Do not place thin plastics into tank	Limit cleaning time to one hour only!
Non-Stick, Teflon, and other coated items	NO	The soak tank will remove any coated surface.
Wood	NO	Water and heat will damage wood.
Electric Items	NO	Water will damage electronics.

DO NOT:

- Place non-stick, Teflon, or any coated items in the soak tank!
- Place wood, thin plastic, copper, gold or other soft metals into the soak tank
- Stick your hands in the hot water! Use the basket!
- Unplug or turn the tank off! The tank doesn't work when its water is cold.
- Open the electrical panel! Only authorized personnel are to open the electrical panel.

TROUBLESHOOTING

If your heated soak tank is cold answer the following questions:

1. Is the soak tank **unplugged?**
(Check plug, unplug, re-plug)
If you answered "YES" to any of these questions, correct the problem and wait **4-6 hours** to see if tank is heating up.
2. Is the soak tank **turned off?**
(Flip switch On/Off, set back to On)
If the tank is still cold please call us at **877-870-5088.**
3. Is the soak tank plugged into a **tripped GFI outlet?**
(Press Reset, press Test, press Reset)
If you answered "NO" to all of these questions please call us at **877-870-5088.**