

Layout Diagram:


Draw your bed size and shape below to help determine how many elements are needed for that great night's sleep!

Hint:

4 rows of 12 equal 1 Froli Travel "Bed in the Box" kit, item #28322, as illustrated by the shaded area below.

Note that smaller, half-size, elements are also available.

We use the medium distance spacing here but rows may also be spaced narrower or wider for an optimal fit.



TRAVEL Medium Spacing

FROLI®_Travel Assembly Instructions



Dear Customer,

We thank you for choosing this FROLI brand product.

Please follow the instructions below to ensure correct assembly and use. For additional questions, please contact your authorized FROLI representative.

We hope that you will enjoy this product and we wish you many nights of healthy, recuperative sleep.

IMPORTANT! READ THESE INSTRUCTIONS BEFORE ASSEMBLY

Assembly

FROLI Travel may be clipped together using a narrow, medium, or wide distance spacing by selecting the appropriate hole spacing on the base element. This feature provides for firmness adjustments in accordance to body weight and personal preference.

The narrow spacing is recommended for a body weight in excess of 90 kg/ 200 lbs.

Hint: Vary the distance spacing lengthwise to create a "His and Hers" side.



Base element for regular size spring.




Base element for small (1/2 size) spring.


NOTE: Small springs and bases are not included with all kits.

Step 1

1. Lay out the base elements on the bed base, usually forming rows across, starting at the head end of the bed.
Hint: The arrow (triangle) mark embossed on each base element helps keep the elements lined up in a uniform fashion.
2. Choose a narrow, medium, or wide hole spacing, keeping in mind that the wider the setting, the softer the feel.
Hint: Use the wide spacing in the leg/feet region to maximize coverage.





3. Connect the base elements by pressing down on the locking knob (1) and sliding it into the adjacent base element to lock the pieces together (2) at the desired distance.



Step 2


1. After assembling the base elements to form a mat, fit a spring element onto the slot in the center of each base element.
2. Turn the spring element through 90 degrees so that the slot engages in the button(s) of the base element.
Hint: Three settings are available to help line up the spring along the sides of angled or curved bed shapes.
3. The light blue (soft) springs are recommended for use in the shoulder area (3rd and 4th row from the top).
4. Unused parts of the base elements may be trimmed off along the bed sides to achieve a close custom fit.



Step 3

The tension clips provided in the package increase lumbar support when added to the center of the springs in the lower back region. They increase the firmness of the spring and may be added at a later time as required.

Simply hook the four ends of the tension clip into the inner ends of the spring element until they are firmly engaged.



International protection rights