


OPERATION

BB-800, 900



BB-1000



Simple Operation Panel (BB-1000 model)



NOTICE

When user does not use remote control for 10 seconds, the LED lamp will turn off in order to save the battery power. (BB-1000 model)

Sit on the seat

- When sitting on the seat, the Orange LED on the control panel will light and the deodorizer fan will start to run.
- Push "SEAT" to adjust temperature.

Push "Dry" function

- You can adjust air temperature by Pushing () or () button.
- Automatically stops after 3 minutes.

Push the desired function button



- All washing functions work for one minute.
- Push "WATER" to adjust temperature.

Nozzle & Move Position Control

- Push () or () to adjust spray position.

How to operate

1st Step

Push "Turbo Wash", "Enema Wash" button, and adjust the washing features on the control center. Adjust "water pressure" and "nozzle position".

2nd Step

After a few minutes, strain your abdomen to eliminate the waste matter from your system. Water inside → Pushing out.

Water Pressure Control

- Push () or () to adjust the water pressure.

Rhythm Wash Control

- Push () MASSAGE button.

Press "Stop" Button to stop all operations.