

ACCESSORIES

Step Up Ring

Male (mm)	27	28	30	30.5	34	37						39	40.5				
Female (mm)	37	37	37	37	37	52	40.5	43	46	49	52	55	58	49	52	43	46
Male (mm)	46					48					49					52	
Female (mm)	48	49	52	55	58	62	49	52	55	52	55	58	62	67	72	77	55
Male (mm)	55					58					62					67	72
Female (mm)	58	62	67	72	77	62	67	72	77	67	72	77	72	77	82	77	82

40.5	43				
49	52	46	48	49	52
52					
58	62	67	72	77	
77	82				
82	86				


Cleaning Kit

- MSJ-001 Portable Cleaning Kit**
- Lens Cleaning Spray
 - Microfiber Cleaning Cloth (15cmx15cm)
 - Cleaning Brush
 - Air Blower
 - Portable Pouch



Step Down Ring

Female (mm)	43	46	52	46	48	49	52	55	58	49	52	55	58			
Male (mm)	37		43	46					48							
Female (mm)	52	55	58	62	67	72	77	55	58	62	67	72	77			
Male (mm)	49					52					52					
Female (mm)	58	62	67	72	77	62	67	72	77	67	72	77	72	77		
Male (mm)	55				58				62				67			



77	82	82	86	86
72	77	82		

- MSJ-002 Lens Cleaning Kit**
- Lens Cleaning Spray
 - Microfiber Cleaning Cloth (15cmx15cm)



How to Maintain the Filter

Daily Maintenance

Blow dirt and dust by a blower or wipe with a cleaning paper or cloth, etc.



For Heavy Stains

For heavy stains, use lens cleaning liquid and a cleaning cloth or paper, etc.

*Care should be taken, as using an abrasive lens cleaner might result in removal of the coating.

Cautions in Conducting Maintenance

Never use water or detergent for cleaning the filter.

*When not used, store the filter in the filter case, in order to prevent adhesion of dust, and scratches.

