MAC FAUCETS

When Style Matters

Installation Instructions



User Manual

Automatic Hand Dryer Model: AHD-3 & Model: AHD-5

Specifications

- ✓ Stainless Steel Front Cover
- 110 120V
- √ 11.7 Amps
- 550 1200W
- Hardwire Connection

Tools Needed


Hammer

- ✓ HEPA Filter
- ✓ All hardware necessary for satisfactory installation






AHD-5










- 1. Use the template provided inside of the box.
- 2. Use a level to insure that the template is straight and level, the electrical box must be a 7/8" from the edge of template to the edge of the box.
- 3. Use painters tape to hold the template in place.
- 4. Drill holes for supplied plastic anchors.




5. Place the plastic anchors in the holes and push them with the help of a lite hammer.








01 Recommended Mounting Heights










- Use Allen wrench from accessories bag to remove 2 countersunk screws from body shell.
- Pull the shell upward by hands to remove.
- ▲ Please avoid damage to shell finish.

Mounting instructions


- Install Electrical Box inside the wall. Location is shown in 2 page 1, point 2 Electrical Box must be flush with the wall surface.
- Pass the electrical cable through the knock out hole before mounting hand dryer onto wall, leave 6"-8" of wire inside of the hand dryer.
- Affix hand dryer onto wall using the 4 supplied screws, fasten securily














Operation instructions



Place hands under sensor to activate. Dryer will shut off a few seconds after hands are removed.

