
NEMO DOUBLE XL

TECHNICAL DATA



76/96



NEMO DOUBLE FITTING INSTRUCTIONS XL



XL		Cal	risa
Assembly Instructions	Key	Component	Qty
Fit bleending valve (B) & blind tap (C).	A	Bleeding Valve Key	1
Use Carisa bleeding valve key (A) to turn bleeding valve (B).	B	Bleeding Valve 1/2"	1
Accurately mark out bracket holes on wall using spirit level.	⊘ C	Blind Tap	1
Drill four 8mm diameter holes for upper brackets (E) and four 8mm diameter holes for bottom brackets(F).	D E	Friction Cups/Cushion Left Bracket	ns 4 2
Friction cups (D) MUST be fitted to each mounting brackets (E,F) to suppress potential noise.	F G	Right Bracket Screw-5,5x45mm	2 8
Screw brackets (E,F) into wall plugs (H) with 5,5mm diameter x 45mm screws (G).	→ H	Wall Plug	8
Hang radiator by sliding the bosses on the back of the radiator into brackets (E,F).	•		
		45	