<u>RETURN PACKING INSTRUCTIONS</u>



 Start with the assembled bassinet. Remove the bassinet board and mattress. Angle the seat recline connectors as far back as they will go (not 90 degree angle).



5. Next place the wrapped brake and 2x bumper bars on top (ensuring the bumper bars are not directly on any part which may cause dents to the foam during transport).

6. Finally arrange the 2x rain covers, 2x mosquito nets and travel organiser around the parts wherever they will fit.



3. Next insert the additional seat and lay it as flat as possible.

2. Insert bassinet matthess and 2x seat liners.



7. Place the bassinet board on top.



4. Put all wheels in bubble wrap bags. Place the large wheels at the top and bottom ends of the bassinet. Place the smaller wheels next to eachother in the



8. Zip on the bassinet apron and insert the manual and welcome note to ensure they won't be damaged during transport.



9. Remove the headbarrier from the seat and insert it between the bassinet apron and bassinet board to avoid being damaged during transfort. Lay the seat facing down on the floor. Wrap the cardboard around the seat recline plastic parts and cardboard sheet over bar.



11. Cover the frame with plastic bag then place the bassinet on top. The bassinet must be facing the same way as the photo above with the recline buttons angled towards the back.



12. Place a foot muff and canopy over each end of the bassinet. Pull the bubble wrap bag over the entire pram.

13. Place the basket plastic into the box. Then with the help of a second person lift the pram into the box.

14. Close the box. If it does not close properly **do not force the box closed**. This may crack the bassinet board. If you can't secure the box closed you will need to take the pram out again and assemble it again.

10. Remove bassinet plastic and collapse frame. Insert protective packaging over all metal frame ends. Insert second cardboard sheet.



15. Re-tape your box securely with lots of tape.

16. Print and place your return label clearly on the box ensuring the barcode is clean and clear.

And you're done!