

## CASCADIAN ICS-CT Series - Cartridge Tank Assembly Instructions



Top Lid: Add O-ring and Lubricant, and then snap into top of tank




Snap CT-Retaining ring in place once lid is inserted in tank



Where CT-Retaining ring is installed



Glue in



Add O-ring and lubricant

Thread in



Add O-ring and lubricant



Insert Assembly made above into bottom of tank and secure with CT-Retaining ring

Note connections marked TANK and RISER

Connect raw water (in) to TANK, Connect treated water (out) to RISER


Support plumbing to reduce chance of leak from O-ring seal



# CASCADIAN® ICS-CT SERIES SCHEMATICS

## RECOMMENDED:

- Install drain on inlet side of ICS-CTS05M(K)
- Install drain on outlet side of ICS-CTP35 and ICS-CTTO(K)
- Plumb raw water into TANK and treated water out of RISER (marked on bottom adapter)
- Support plumbing to reduce chance of leaks around O-ring seal



## EASY REPLACEMENTS NO TOOLS REQUIRED

1. PRESS THE RED PRESSURE RELIEF VALVE TO UNSEAT THE RING



2. REMOVE SNAP RING



3. LIFT TOP CAP

