

Wagnetic Sweeper Instruction Manual





2. ATTACH RELEASE BAR (Figure 2)

Attach top of Release Bar(C) to pull lever by aligning holes and placing a hex bolt through a washer and into the hole Pull Lever(B). Place a washer between the Release Bar(C) and Pull Lever(B), then secure wish washer and locking hex nut. For the bottom of the Release Bar(C), align the Eyebolt hole with a washer and then place the hex bolt into Eyebolt.

Place washer between the Eyebolt and both sides of the Release Bar(C) and secure with a locking hex nut.