


KEYBOARD MOUNT

Assembly Guide



IMPORTANT: Different regions may have different models. Please ensure the part number below matches that on your product's box.

TR-FLKBM



TRAK RACER

Published May 7, 2025

TABLE OF CONTENTS

3 Symbol Legend

4 Part List

5 Assembly Notes

8 Assembly Instructions



IMPORTANT: Since there are different versions of each product based on your region, please make sure you are using the correct set of instructions. The part number below should match the one on your box.



IMPORTANT: Due to the nature of cut aluminum profiles, some metal shavings may remain despite our thorough QA cleaning process. We recommend opening boxes and packaging on a hard surface.



NOTE: Some screws and washers may be pre-installed. These are included in the parts list and will need to be loosened and reattached according to the instructions.



Recommended: Two people for the task



Tighten the hardware



Keep the hardware loose for adjustments



Make the necessary adjustments



Break the tab off the corner bracket



Safety glasses required



Attention/Priority needed




Reserve for the next step



Mirrored components (same on both sides)


PART LISTS



Circular Base Assembly

CBA

x1



Connecting Rod Assembly Keyboard Pad


CRA

x1



KP-1


x1



Mouse Pad


MP-1

x1



Keyboard Mouse Panel Component
KMPC


x1



Support Tube Assembly

STA


x1



M8x16 Washer (Flat)

WF-M8-16


x2



M10 Washer (Curved)

WC-M10

x1




M10x55mm

M10x55 Button Hex Screw

SR-M10-55

x1




M8x20mm

M8x20 Button Hex Screw


SR-M8-20

x2


INCLUDED TOOLS



INSTALLATION ORDER FOR SCREWS & WASHERS







HOW TO MEASURE SCREWS




NOTE

The handle screws (S7 & S27) are ratcheted to allow for tightening and loosening when space for rotation is limited. Simply pull the handle out and turn handle into position and push handle back in to engage thread.





NOTE

These parts are adjustable and can be rotated to fit comfortably after installation.







NOTE



These parts are adjustable and can be rotated to fit comfortably after installation.



1








2






Note:

Before assembling, remove screws and flange nuts from the support tube assembly.



3





4




5




6





FINISHED



Share your build online and tag us to be featured!



@trakracer



@trakracer



@trak_racer