

ITO FLOOR LAMP

CARE INSTRUCTIONS



General Handling Instructions


Ito weighs about 32 kg. Due to the weight and fragility of the product, it is recommended to have two people involved whenever moving the light fixture for safe handling. When handling, ensure that your hands are clean. It is advised to wear gloves (provided in packaging) to avoid leaving any fingerprint marks on the metal surface and cotton threads. In case the frame is not aligned, check knobs for stability. Tighten gently if necessary, avoiding over-tightening. After unpacking, it is advised to use a steam iron to gently straighten the threads. Do not use hands or a comb. Simply steam iron from all four sides to let the threads naturally fall in place.

Please be wary of the weight. Handle with care.



Metal Frame Care

Ito comprises sand-casted brass rods left in their natural finish. Over time, the metal surface will gradually age. To retain the original finish, use metal polish with a soft, dry cloth and gently rub it onto the surface. Wipe with a clean cloth afterward to remove any polish marks. Do not use any abrasive substance on the frame.



Thread Care

Ito comprises dedicated cotton threads treated with a fab-guard solution that helps the threads resist dust and stains. The cotton threads are also water-repellent. However, over time, dust may settle on the threads. It is suggested to occasionally use a vacuum cleaner and run it over the threads very gently, ensuring that no threads become entangled in the process. It is advised not to pull or shake the threads with force as it may result in the thread being pulled away from the frame.

For any queries, write to us at info@stemdesign.co