RYER MOUNTING TEMPLATE

Fix this card to the wall.

Drill 4 holes

(A. B. C. D. 5/16" (8mm) diameter: 1-3/8" (35mm) depth.)

CONNECTIONS:

- A. Connect the live wire (colored Brown, Red or Black) to the terminal block marked "L".
- B. Connect the neutral wire (colored Black, Blue, White or Grey) or connect the second live wire (colored Red or Orange) to the terminal block marked "N".
- C. Connect the ground wire to the terminal block marked "-" or to the green screw marked "-". Bare grounding (earth) wires should be sleeved with green and yellow or green tubing. Colors of live and neutral wires depend on voltage of supply service and requirements of Building and Electrical Code having jurisdiction.



Recommended Mounting Heights

From bottom edge of dryer above finished floor (AFF)

1200mm Women: Children 4-7 Years: Children 8-10 Years: Children 11-13 Years: 1200mm 850mm 950mm Children 14-16 Years:

1150mm Accessible Compliant: Where provided, hand dryers shall be installed with the height of their operative component or outlet not less than 900mm and not more than 1100mm above the plane of the finished floor, and no closer than 500mm from an internal corner. (Refer-AS1428.1-2009, Clause 15.4.)

Mounting Template, please ensure the PDF document is printed at Actual Size. If you are unable to print to scale, the use of the measurements on the installation template is paramount. Metlam Australia does not take responsibility for the incorrect print out of mounting templates which result in inaccurate mounting holes being drilled during Hand Dryer installation.



(100cm) from floor.

(See mounting chart above.)

When printing the downloadable Hand Dryer

Important Information This Product falls within the scope of the Waste Electrical & Electronic Equipment Directive 2002/96 EC. (WEEE)





7/8"

(Ø22mm) ELEC.K.O